


Tube heat exchanger 4, 5 & 6

Datasheet

For installation instructions, see manual for Truck Master Series.



Metric

Model	A	B	C	D	E	F	G	H	I	J	K	Weight
Tube heat exchanger 4	1200 mm	250 mm	101 mm	Ø89 mm	556 mm	Ø25 mm	Ø25 mm	1½"	Ø32 mm	Ø25 mm	M10	8 kg
Tube heat exchanger 5	1280 mm	280 mm	127 mm	Ø114 mm	570 mm	Ø25 mm	Ø25 mm	2"	Ø32 mm	Ø25 mm	M10	11 kg
Tube heat exchanger 6	1280 mm	300 mm	156 mm	Ø133 mm	570 mm	Ø25 mm	Ø25 mm	2"	Ø32 mm	Ø25 mm	M10	14 kg

Imperial

Model	A	B	C	D	E	F	G	H	I	J	K	Weight
Tube heat exchanger 4	47.2 in	9.8 in	4.0 in	3.5 in	21.9 in	1.0 in	1.0 in	1.5 in	1.3 in	1.0 in	M10	17.6 lb
Tube heat exchanger 5	50.4 in	11.0 in	5.0 in	4.5 in	22.4 in	1.0 in	1.0 in	2.0 in	1.3 in	1.0 in	M10	24.3 lb
Tube heat exchanger 6	50.4 in	11.8 in	6.1 in	5.2 in	22.4 in	1.0 in	1.0 in	2.0 in	1.3 in	1.0 in	M10	31.0 lb